




Lista cz ci




AX1




BX1



CX1




DX2



EX4



FX12



GX4



KX8



IX16



LX8




HX16



MX8



JX1




NX1




LX1


1



2



3



4

